

WEEE Number: 80133970

## INSTALLATION INSTRUCTION SOLAR LED WALL LIGHT (VT-982)

### TECHNICAL DATA:

|                  |                             |
|------------------|-----------------------------|
| SKU              | 2892                        |
| LUMENS           | 110LM                       |
| NO. OF LEDs      | 24 Pcs                      |
| BEAM ANGLE       | 170°                        |
| DIMENSION        | 17.5x20x23mm                |
| BATTERY CAPACITY | AC: 3.7V, 2200mAh, 18650 Li |

### SOLAR PANEL DATA:

|                   |              |
|-------------------|--------------|
| SOLAR PANEL WATTS | 2W, DC: 5.5V |
| CHARGING TIME     | 5-6 Hours    |
| WORKING TIME      | 3-12 Hours   |




### INTRODUCTION & WARRANTY


Thank you for selecting and buying V-TAC product. V-TAC will serve you the best. Please read these instructions carefully before starting the installation and keep this manual handy for future reference. If you have any another query, please contact our dealer or local vendor from whom you have purchased the product. They are trained and ready to serve you at the best. The warranty is valid for 3 years from the date of purchase. The warranty does not apply to damage caused by incorrect installation or abnormal wear and tear. The company gives no warranty against damage to any surface due to incorrect removal and installation of the product. This product is warranted for manufacturing defects only.!

### ! WARNING


1. Installation must be performed by a qualified person.
2. The light source of this luminaire is not replaceable, when the light source reaches its end of life the whole luminaire should be replaced.
3. Replace any cracked protective shield.
4. Don't immerse in the water
5. Luminaire cannot be installed in low-lying areas, so as not to soak.



This marking indicates that this product should not be disposed of with other household wastes.




Non-replaceable light source



**MULTI-LANGUAGE  
MANUAL QR CODE**

Please scan the QR code to access the manual in multiple languages.

### INSTALLATION DIAGRAM:



### INSTALLATION INSTRUCTION

1. Drill the holes in the wall.
2. Dig the plastic into the hole.
3. Fix the wall plate onto the wall.
4. Fix the lamp body on the plate and tighten the screws

### SWITCH FUNCTION:

- Towed the switch to the right: to change the color into Warm White
- Towed the switch to the left: to change the color into White
- Towed the switch to the middle: to switch off the light

### OPERATING MODES:

- At the dusk, automatically turn on the light to 100% brightness. (up to 12 hours)
- At the dawn, light will automacally turns off