


# MANUEL

---

## 1. Afmeting:



## 2. Gebruiksaanwijzing:



### **Aan/Uit:**

Het witte licht gaat aan door op de knop te drukken en ondertussen wordt de 1e module (45°C) van de handwarmer geactiveerd. Nogmaals drukken, het oranje licht gaat aan en de 2e module (55°C) wordt geactiveerd. Druk de 3e keer en het licht en de warmere functie zijn uit.

### **Type-C recharge input:**

Max 5V/2A, wanneer hij aan het opladen is zal het rode lichtje branden. Wanneer de handwarmer volledig is opgeladen is het lichtje uit.

Het rode licht zal flikkeren wanneer er een handeling plaatsvindt.

# MANUEL

---

## 1. Dimensions:



## 2. User manual:



### **On/Off:**

The white light comes on by pressing the button and, meanwhile, the 1st module( 45°C) of the hand warmer is activated. Press again, the orange light comes on and the 2nd module (55°C) is activated. Press the 3rd time and the light and warmer function are off.

### **Type-C recharge input:**

Max 5V/2A, when it is charging, the red light will come on. When the hand warmer is fully charged, the light will be off.

The red light will flicker when an operation takes place.