



Meaningful Innovation.

WEEE Number: 80133970

INSTRUCTION MANUAL

LED OUTDOOR WALL LIGHT
UP & DOWN

TECHNICAL DATA

MODEL	VT-1192
SKU/COLOUR	10564/3000K 23027/4000K
TOTAL POWER	15W
MODULE POWER	
TOTAL VOLTAGE/FREQUENCY	AC: 200-240V, 50Hz
MODULE VOLTAGE	
TOTAL CURRENT	240 mA
MODULE CURRENT	
LUMENS	1950 Lm
BEAM ANGLE	100°
CRI	>80
LIFE SPAN	20,000 Hours
ON/OFF CYCLE	>15000
DIMENSION	L160xW165xH164mm



IP65
RATING

02 YEAR
WARRANTY*

INTRODUCTION & WARRANTY

Thank you for selecting and buying V-TAC product. V-TAC will serve you the best. Please read these instructions carefully before starting the installation and keep this manual handy for future reference. If you have any another query, please contact our dealer or local vendor from whom you have purchased the product. They are trained and ready to serve you at the best. The warranty is valid for 2 years from the date of purchase. The warranty does not apply to damage caused by incorrect installation or abnormal wear and tear. The company gives no warranty against damage to any surface due to incorrect removal and installation of the product. The products are suitable for 10-12 Hours Daily operation. Usage of product for 24 Hours a day would void the warranty. This product is warranted for manufacturing defects only.



MULTI-LANGUAGE MANUAL QR CODE

Please scan the QR code to access the manual in multiple languages.

INSTRUCTIONS FOR THE LIGHT

1. Please make sure to turn off the power before starting the installation.
2. Installation must be performed by a qualified electrician.
3. The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.
4. Proper grounding should be ensured throughout the installation.
5. For Indoor Use only



This marking indicates that this product should not be disposed of with other household wastes.



Caution, Risk of electric shock


*This product contains a light source of energy efficiency class<F>, where <F> shall be replaced by the energy class of the contained light source.




RoHS



INSTALLATION DIAGRAM



WIRING DIAGRAM



1. Switch off the power before starting the installation.
2. Use screws to fix mounting bar to the junction box.
3. Make the wire connections with connectors.
 - Connect the live wire (L) from fitting to the live wire from main power supply.
 - Connect the neutral wire (N) from fitting to the neutral wire from main power supply.
 - Connect the earth wire from fitting to the earth wire from main power supply.
4. Use screws to fix canopy to mounting bar.
5. Check if the installation is completed and turn on the power

Note: This light is designed with adjustable height, press the pin on the canopy to adjust the height of the light.

