尺寸：100x130mm

Jibeufi

Desktop Air Conditioner Fan



（**Instruction Manual**）

Thank you for using our product, please
read the product manual carefully before use.

Desktop Air Conditioner Fan

⚠ Please add tap water or mineral water

PROCUCT STRUCTION CHART



1.Water tank buckle
2.Water tank
3.Wind guide
4.Radiator cap
5.Handle design
6.DC power port

Please note:
Connecting to the DC power part must be > 10W
(5V 2A) otherwise the machine can notwork

KEY FUNCTION EXPLICATION



ON/OFF

Press the first gear to turn on the indicator light, then press the second time to turn on the second gear to turn on the indicator light, then press the third time to turn on the third gear to turn on the indicator light, then press the fourth time to turn off the machine.

TIME

Single press the timing 2H timing shutdown.Second press the timing 4H timing shutdown. Three Press to turn off the timing. cycle operation.

COOL

Single press to turn on the spray function. Two presses to turn off the spray function and cycle operation.

LIGHT

Power on state, single press the ambient light to turn on, the colorful lights will automatically change and cycle, and the operation will be cycled. Press again to turn off the ambient light.

USE INSTRUCTIONS

1.This is a personal air cooling device. It' s good for up close or small spaces. Just don't expect it to cool your entire room.
2. Before opening the product, please read the instruction manual carefully, take out the product, and place it on a horizontal table.
3.Open the water injection port and add clean tap water. Do not add water more than the maximum water level, then close and tighten the water cap.
4. After the machine is turned on according to the operating instructions, operate the machine as required.



The upper cover can be rotated to open.

Connect the charging port on the product (Use with 5V2A or higher adapter)

Ice water addition method

COMMON PROBLEMS AND SOLUTIONS

Problems	Reference solution
The spray is not cooled when the air is turned on	If the water shortage indicator icon lights up, it indicates that the machine is already short of water. You can add clean water and press to open the mist.
Sudden crash	Check whether the battery power of the product has been prompted for a low battery phenomenon.

CONSIDERATIONS

1. The product should be placed on a flat surface during use, and be careful not to cause the product to roll over or collide during use.
2. The water added to the product must be clean tap water or purified water, and detergent, unknown liquid, chemical agent, etc. cannot be added to the water tank to start atomization.
3. Please add water to the product when the product is powered off.
4. If the electronic control part is accidentally immersed in water, which results in garbled display and key failure, please do not continue to use it. It can be placed in a dry place to wait for the water to dry or directly use an external fan to dry the water traces before attempting to power on.

5. Replace the water in the water tank every day, and clean the inside of the water tank regularly to keep the inside clean to avoid the growth of mold or odor.
6. The water tank can be used with pure water or tap water ice cubes. Please do not use silica gel ice. If the water in the water tank is frozen, do not use it.
7. There can be no objects blocking the air inlet/outlet.
8. Please don't give the elderly, infants or people with limited mobility to directly fix the air for a long time, so as not to cause discomfort.
9. Do not approach furniture, curtains, walls, etc. during use to avoid discoloration, staining, deformation and other problems.
10. Do not blow air to other household appliances at close range in the fogging state, so as to avoid other products from malfunctioning.
11. Please avoid direct sunlight or place it around heating appliances.
12. Please use a suitable power supply to charge the machine.
13. When the product is not used for a long time, the product should be turned off, and the water tank should be kept dry and clean.
14. Please clean the product after turning off the power to avoid accidental electric shock.
15. Please do not disassemble the product by yourself, so as to avoid damage to the product and cause accidents.
16. Please place it out of the reach of children, do not let children use it alone.
17. Please do not put fingers, body parts or debris into the air inlet/outlet to avoid injury.
18. Please do not open the water tank during the fogging work, and do not touch the atomizer sheet with fingers and body parts to avoid injury.

TECHNISCHE DATEN

Product Model	YP2201
Voltage	≤10W
Current	≤2A
Rough weight	0.98kg
Wind speed level	Ⅰ Ⅱ Ⅲ
Water Tank Capacity	450ml
Product Size	223*148.5*164 mm
Display method	Display Screen



（取り扱い説明書）

お買い上げ頂き、誠にありがとうございます。本製品を使用する前に、取り扱い説明書をよく読んでください

製品構造説明



1.ボタン
2.水槽
3.ウィンドガイド
4.ラジエーターキャップ
5.ハンドルデザイン
6.DC電源ポート

注意ください
dc電源部への接続は&gtでなければなりません;10W
(5 v 2 a)そうしないとマシンが動かない可能性があります

ホストボタンの説明



ON/OFF

1段の風をオンにして、ランプが点灯して、更に短押し2回目、2段の風をオンにして、ランプが点灯して、更に短押し3回目、3段の風をオンにして、ランプが点灯して、更に短押し4回目、シャットダウンします。

TIME

タイミング2Hタイミングシャットダウンを1回押します。次に、タイミング4Hタイミングシャットダウンを押します。3回押すと、タイミングとサイクルの動作がオフになります。

COOL

スプレー機能をオンにするには、1回押します。2回押すと、スプレー機能とサイクル操作がオフになります。

LIGHT

電源オン状態、アンビエントライトを1回押すとオンになり、カラフルなライトが自動的に変化して循環し、操作が循環します。もう一度押すと、周囲光が消えます。

使用説明

1.これは個人用の空冷装置です。近くや
小さなスペース。部屋全体が冷えるとは思わないでください。
2.開封する前に、取扱説明書をよくお読みになり、取り出して横置きにしてください。
3.給水口を開き、きれいな水道水を追加します。追加する水の量は、最高水位を超えないようにしてから、給水キャップを閉じて締めます。
4.取扱説明書に従って本機の電源を入れた後、必要に応じて本機を操作してください。

アッパーカバーは回転させる開くことができます

充電ポートを製品に接続します（5V2A以上のアダプターで使用）

水や水を加えることができます

一般的な問題と解決策

問題	リファレンスソリューション
空気を入れてもスプレーは冷却されません。	水不足インジケータアイコンが点灯している場合は、マシンの水が不足していることを意味します。あなたはきれいな水を加えて、蓋を開くために押すことができます。
突然クラッシュします。	製品のバッテリー残量が低いバッテリー残量を示しているかどうかを確認してください。

注意事項

1.使用中は平らな面に置いてください、また、使用中に転倒したり衝突したりしないように注意してください。
2.製品に添加する水は、きれいな水道水または精製水でなければならず、洗剤、未知の液体、化学薬品などを水タンクに添加して噴霧を開始することはできません。
3.製品の電源がオフになったら、製品に水を加えてください。
4.電子制御部品を誤って水に浸し、表示が文字化けしてキーが故障した場合は、使用を継続しないでください。乾燥した場所に置いて水が乾くのを待つか、外部ファンを直接使用して水の痕跡を乾かしてから電源を入れます。

5.毎日水槽内の水を交換し、カビや臭いの発生を防ぐため、水槽内を定期的に清掃して内部を清潔に保ってください。
6.水槽は、純水または水道水角氷で使用できます。シリカゲルアイスは使用しないでください。水槽内の水が凍結している場合は、使用しないでください。
7.空気の入口/出口を塞く物体があってはなりません。
8.高齢者、乳幼児、身体の不自由な方は、不快感を与えないように、固定された場所に直接長時間放置しないでください。
9.変色、汚れ、変形などの問題を避けるため、使用中は家具、カーテン、壁などに近づかないでください。
10.他の製品の誤動作を防ぐため、量りの状態で近距離にある他の家電製品に空気を吹き付けないでください。
11.直射日光を避けたり、暖房器具の周りに置いたりしてください。
12.適切な電源を使用して機械を充電してください。
13.製品を長期間使用しない場合は、製品の電源を切り、水タンクを乾燥させて清潔に保つ必要があります。
14.偶発的な感電を防ぐため、電源を切った後は製品を清掃してください。
15.製品の損傷や事故の原因となることを避けるため、製品を自分で分解しないでください。
16.お子様の手の届かないところに置いてください。お子様が一人で使用しないようにしてください。
17.怪我をしないように、空気の入口/出口に指、体の部分、または破片を入れないでください。
18.量り作業中は水タンクを開けないでください。また、怪我をしないように、指や体の部分でアトマイザーシートに触れないでください。

仕様

製品モデル	YP2201
電圧	≤10W
電流	≤2A
粗重量	0.98kg
風速レベル	Ⅰ 簡単
水槽容量	450ml
商品サイズ	223 * 148.5 * 164 mm
表示方法	表示画面