


Mandoline Slicer Instructions




▪ How to use




1. Unfold the legs and set the mandoline on a solid surface.



2. Press and counterclockwise rotate the knob, then remove the blade cover



3. Press and clockwise rotation to the desired setting, then release it.



4. Use the food holder, keep a back-and-forth motion keeping the food holder in contact with the base until the vegetable is sliced.

▪ How to disassemble and clean



1. Push and rotate the knob to "OUT"
2. Lift the panel
3. Lift up the knife shaft




rinse under
running water




Dishwasher
Safe

■ How to put it back



1. Aim the bulge on the knife shaft at the hole on the mandoline
2. Press the knife shaft down until they click into placet



Product Function And Use

Julienne



Thick julienne
9mm



Thin julienne
4.5mm



Slice (1-9MM)



Slices 3 kinds
9mm




Slices 3 kinds
6mm




Slices 3 kinds
3mm



■ Cautions





Hands operation



Single hand operation

