

材质：100g书纸 两面印刷
尺寸：132*80mm

DDPAI
Image my world

mix3

User's Manual

1. CAUTION

- This device is designed to record video while the vehicle is in operation. It can record ultra HD video even when there aren't streetlights around.
- Keep the windshield and lens clean for optimal video quality.
- Do not leave the device in vehicle without fixing firmly, fix device onto a clean windshield where the vision is not blocked. Don't install device on air bag or within its working range.
- Only use the power cable provided by the manufacturer. Other power cable may cause short circuit, fire, or malfunction.
- This device adopts built-in SD card, featuring in high efficiency, stability, long use life. The memory card should be formatted via App or PC regularly to maximize the lifetime of the memory card.
- Do not adjust DDPAI Dash Cam or watch real time video via App while driving.
- Do not install the product in a location where the product can interfere with the driver's field of vision.
- Improper battery replacement may cause explosion, use the same type or battery to replace; Do not expose battery (cell battery or Li battery) in the sunlight or such extremely hot environment. Do not damage, puncture the battery or put it in the fire, doing so may cause explosion or toxic chemicals release.
- The product optimal temperature range (-20°C ~ 70°C/4°F ~ 158°F), it provides high temperature protection function, it shuts itself down to prevent any damages at very extreme temperatures (working temperature range is 0°C-50°C/32°F ~ 122°F when powered by battery).
- Do not disassemble or repair the product by yourself, contact our service expert in case of any issue.
- This Dash Cam can be used in other occasions despite in vehicle, supply by power adapter.
- The contents of this manual are for reference only.

2. PACKAGE CONTENTS

3. WORKING STATUS

Power Button: Press and hold for 2 seconds to turn the device on/off, press one time to turn the IFS screen on/off while the Dash Cam is working.

Parking Mode LED: Blinks slowly in parking mode. (solid on indicates USB data transmission mode).

Working Status LED: Blinks slowly in normal working mode.

- Both LED are blinking quickly indicate memory card error.
- Both LED are solid on indicate firmware upgrading.

Controller Button
Control Buttons to navigate through user menu on the screen.

4. USING THE DASH CAM

You can use/setup your Dash Cam via control buttons or DDPAI App.

Control Button
After connect and power on your Dash Cam, it will bring you to real-time screens. Here you can view recording status, current time, Wi-Fi status, audio status, battery remaining.

5. WI-FI INFORMATION

Wi-Fi Information
View Dash Cam Wi-Fi information: turn on/off camera Wi-Fi. Turn on: App can find and connect to camera Wi-Fi. Turn off: App can not find camera Wi-Fi.

Loudspeaker
Turn on: there will be voice guidance and alert/notification sounds. Turn off: there will be no voice guidance and alert/notification sounds.

Parking Monitoring
Turn on: When your car has been stationary for 15 minutes, Parking Monitoring is automatically activated, stay on for the selected time duration (select from App: 15 minutes, 1H, 6H, 24H, or no shut down), and automatically deactivated and switches back to continuous recording when there is a motion. Turn off: When your car has been stationary for 15 minutes, Dash Cam will automatically shut off.

NOTE

- Use extra hardware kit need to be installed on: no need hardware kit at all if your car has an active cigar lighter (i.e. when car engine is off, the cigar lighter still supply power).
- Select parking monitoring time duration and turn on/off parking monitoring from App.

6. INSTALLATION

5.1 Installing the Dash

- Clean the area on the windshield where the Dash Cam will be installed, otherwise it may fall off easily in later.

5.2 Installing the App

NOTE

- This App is certified virus-free by Google Play Store and Apple App Store, it does not contain malware, please list it in your trust application list. We don't collect any kind of personal data, the information collected about you only for register purposes.
- The DDPAI App is release for devices running Android 4.0 and up, iPhone 4 and up, or iOS 7.0 and up.
- Some customized Android smart phones need to turn off mobile data(GSM, 4G) to connect to Dash Cam via Wi-Fi, please be noted that the Dash Cam keeps working without connecting to smart phone.

5.3 App Overview
Here is an overview of DDPAI Dash Cam App.

NOTE
Camera LCD screen will be locked while App accessing. After exit App, it will unlocked automatically.

Camera
After connecting your phone with the DDPAI Dash Cam Wi-Fi, open the App, from here you can add/delete Dash Cam, and preview, playback, download, snapshot, cropping etc.

On the Road
DDPAI users community, it only need to connect to your smart phone data or home Wi-Fi. From here you can find nearby users, see the newest activities, user experience, installation tutorial etc.

Sharing on Social Media
Tapping on icon to share picture or video on social media like Facebook, Twitter.

Albums
View images, videos and emergency clips, you also can edit and share them from here.

Me
Hardware settings, updating and help center.

5.4 Pair Smart Phone

- Launch App, tap on Camera, then tap on...
- Choose your DDPAI Dash Cam from the network list (For Android system, App will start to search Dash Cam network automatically. For iOS phone, turn on WLAN from Settings > WLAN. The Dash Cam default SSID (Wi-Fi name) begins with "vYou", ends with its model (e.g. vYou_DDPAI_mix3).
- Enter the camera's default password "1234567890".
- Click ADD CAMERA, wait a few seconds until the preview screen show.

NOTE
Direct Wi-Fi will turn on automatically when the Dash Cam turn on.

6. USING THE DASH CAM VIA APP

6.1 Preview
You can view in real-time the video currently being recorded by connecting your smart phone to the Dash Cam via direct Wi-Fi. 1) Open the DDPAI App, and add your Dash Cam. 2) Select Camera tap, then tap on (Q) button, this will bring you to preview page.

NOTE

- The download speed is about the same as the video playback speed. The video which is downloaded to the mobile phone is compressed, the HD video is stored on the built-in memory card.
- Emergency G-Sensor video storage to emergency file video.
- App will automatically download the video which was not completely downloaded last time once connect to dash cam.
- HD video is in MP4 format and can be viewed in the computer.

6.2 Video Playback, Download video/images, etc.
Rotate your smart phone or press expand icon, turn preview screen to landscape mode.

Aspect ratio setting
Resolution setting
Download images/video
Time line bar
Tip: if the time line bar not display, tap on video screen.

Video Playback
Tap and left/right drag time line bar at the screen bottom to create the starting point of the recording you wish to preview, then tap on thumbnail when you have made your selection, or wait for 3 sec for buffering, now you can watch the history recording.

Resolution Settings
Tap on FHD to set the video/ photo resolution, if the FHD icon is not showing, tap on the video screen.

Download Image/Video Files
Tap on from preview screen to select image or video to download. Tap on from preview screen to select image or video to download.

download image files
download video files

For image files:
The emergency image and other image taken by Remote Snapshot can be downloaded automatically by: Going into Me > Settings, turn on Auto Download Snapshot. However, image taken by Shutter Button will be always downloaded automatically.

For video files:
Drag timeline bar to create the starting point.
Tap it to start download
Tap it to end and download

After downloading, you can share it on social media or delete it.

NOTE
You can download maximum of 5 minutes length clip.

7. MANAGE FILES VIA SMART PHONE

6.1 Download Emergency Files
1. Connect your Dash Cam to App. 2. Tap on Camera, tap on (Q), then you can select the emergency image or video files.

6.1 Editing and Sharing image/video files
The photo filters integrated into the DDPAI Dash Cam App is configured with 15 photo filters which can be applied to your photos. 1. Tap on the album icon (located at the bottom middle of the screen). 2. Select or tap on the photos you wish to edit.

3. Once selected, at the bottom of the screen there will be an icon that looks like a magic wand, this is the Modify icon. 4. Tap on the Modify icon to open the photo editor. This will activate different photo filters. 5. Select the photo filter you would like to apply by tapping on the filter; on this screen, you also can add Subtitles and Frame like movies. 7. Tap on save icon to apply. You also can share it on social media by taping on Share the picture button.

8. MANAGE FILES VIA PC

- Access memory card of your Dash Cam from PC with USB data cable.
- Double click on movable disk, open DCIM folder, there will be 4 folders under it.

8. SETTINGS

- Connect your Dash Cam with DDPAI App.
- Tap on Me > Settings > Camera Settings.

Camera volume
Use the volume slider to adjust the Dash Cam volume.

Microphone Recording
When turned off, the dash cam does not record audio.

9. FAQ

1. Video Recording
Q1: Shall I keep the dash cam connected with my phone when it is working?
A: The Dash Cam starts to record videos automatically when the car is started without needing to connect to your phone. However, if they are connected, you can preview, download, and playback the videos from the App on your phone.

Q2: Why some of the Dash Cam video recordings are missing.
A: Make sure the App's firmware are the latest version. If there is "Storage exception" notification opens the SD card is corrupted and need to be replaced.

Q3: Why image is not clear in my smart phone?
A: The video downloaded to your smart phone is compressed, you can review HD recordings via PC in MP4 format.

2. Wi-Fi and App Connectivity
Q1: How to change the Wi-Fi name and password of the Dash Cam?
A: Make sure your Dash Cam is connect to App, then go into Me > Settings > Camera Settings, tap on Camera Name to change your Wi-Fi name, tap on Camera Password to change your Wi-Fi password.

Q2: WiFi is always disconnected?
A: Go into Settings > Wi-Fi and hit the menu button, select Advanced, disable "Scanning always available". If "Scanning always available" checkbox is checked, make sure your smart phone is near the Dash Cam. Make sure your devices are not surrounded by too many Wi-Fi networks.

Q3: After connected with the Dash Cam Wi-Fi, why can't my Android access it's mobile data.
A: Due to the settings of Android phones, mobile data is no longer available when it's connected to the Dash Cam Wi-Fi.

Q4: Why cannot add camera/ adding camera failed?

Q5: Why App cannot find Dash Cam Wi-Fi?

11. Upgrade the Firmware via App
Our App and camera firmware will be updated regularly, you can update the firmware via App. Please follow these steps to upgrade the DDPAI App and the latest firmware version onto the DDPAI Dash Cam. 1) Open the Wi-Fi settings of your mobile device and connect to the Dash Cam via Wi-Fi. 2) Once you are connected, launch the App. You will get a notification asking you to upgrade, accept to upgrade. 3. If you don't get the notification, you can tap on the Me in the lower right corner of the App to manually upgrade.

Tap on see more to view more information about your Dash Cam. If an update is available, a will appear. Tap on the New firmware available to bring up the download page. If the App is the latest version, a notification of "Current version is the latest" will pop-out.

11.2 Upgrade the Firmware via PC

- Access your Dash Cam via PC with USB data cable.
- Download the latest firmware for your camera, unzip and copy the content you have unzipped onto the built-in flash card.
- Power on the camera and it will apply the firmware automatically.

NOTE

- Your Dash Cam's two LED indicator should blink during the upgrading.
- Once the dash cam is done upgrading it will tell you that "Upgrade success". Do not power off your Dash Cam until it begins continuous recording as it may cause permanent damage to the Dash Cam.

11. SPECIFICATIONS

CPU: H3316E, H 265/H 264(4k@60), 1080P@30fps
Image Sensor: SPMF low illumination CMOS sensor
Lens: 6 G-lenses, 140° wide angle, F1.8
Screen: 5 inch IPS screen
Wi-Fi Module: Wi-Fi 2.4GHz
Video Output: Wireless video output, support Android/iOS device
G-Sensor: Built-in MEMS high speed fast, loop recording
Video Resolution: 1920*1080 @ 30fps
Photo Resolution: 1920*1080
RAM: 512MB

12. CUSTOMER SUPPORT
For customer support and firmware updates please visit www.ddpai.com. You can also email a Customer Support expert at feedback@ddpai.com. Find us on Facebook, Instagram at [ddpaiofficialcam](https://www.facebook.com/ddpaiofficialcam). Or you also can contact us on Facebook and WeChat by scanning below QR Code: